STRAIGHTENING B&B GRAPE AND HYALURONIC

Method of use

STEP 0 - Hair Diagnose

- Keratin maximum straightening treatment
- Suitable for all types of hair from fine to very resistant
- Recommended for straightening, moisturizing and removing frizz
- Result: maximum straight, repaired and smooth hair

STEP 1 - Deep Cleansing Shampoo

- Wash hair with the shampoo and leave on for 5 minutes (exactly)
- Rinse with plenty of water
- Repeat this process 2 or 3 times minimum, until the hair is very clean and has an almost rough touch
- Remove dampness with a towel (**Do not use a hairdryer**)
- Tips for a perfect wash:
 - Do not rub hair roots too much
 - Massage the entire length of hair
 - o Pay special attention to the back of the neck

STEP 2 -Keratin Straightening

- Vigorously shake the treatment bottle (important)
- Use gloves, a bowl and a palette
- Put 30-50g of the Step 2 in the bowl, depending on the length/thickness of the hair
- To achieve an extra straight result, add ampoule C and mix
- Apply the treatment with the pallet, grabbing fine locks of hair

- Start with the back of the neck at 1 cm of the root
- Use enough product to cover all the lock
- Run a fine comb to remove the excess
- Leave on between **15-30 min** depending on how straight you want the hair and the duration of the result you want to (4-6 months)
- <u>DO NOT RINSE</u>, detangle hair with a comb
- Dry down aligning with hands (no brushing required) with cold or warm air (not hot) until hair is completely dried
 When you think it is fully dried, dried it even more: it must be fully dried
- Prepare the straightener between 180-230°according to the hair:
 - Thin, bleached and damaged hair: 180°C
 - o Normal hair: 200°C
 - Thick and resistant hair: 230°C
- Make partitions and divide hair in fine locks in order to straighten it (the hair has to touch the straightener on the upper and the lower part)
- Start on the back of the neck and run **7-12 times** each lock according to the type of hair
- In very damaged ends, run less times

TIPS - Last Recommendations

- It is possible to wash the same day with salt-free products (Sodium Chloride)
- For longer lasting results, use the **B&B** salt-free lines

